

PPA28

PP tape with acrylic adhesive, suitable for long-term storage of light weights and for professional and do-it-yourself applications.

ADVANTAGES AND PERFORMANCES

- Good adhesiveness on irregular surfaces
- For manual and automatic use



TECHNICAL PROPERTIES		tolerance	test method
Backing: Adhesive: Total thickness: Film thickness: Tensile strength: Elongation at break: Adhesion to steel: Temperature resistance: Colour:	BOPP water-based acrylic emulsion 48 µm 28 µm min. 32 N/cm min. 120 % min. 4,5 N/cm room temperature brown, white and transparent	± 5 %	AFERA 5004 AFERA 5004 AFERA 5001

The above values are the result of arithmetic averages from tests on sample productions and are not legally binding.

ARTICLES, DIMENSIONS AND BARCODES	dimensions	pieces per box	barcode
PP A 28my brown noisy:	50 mm x 66 m	36 rolls	8051499033415
PP A 28my brown noisy:	50 mm x 132 m	36 rolls	8051499033422
PP A 28my white noisy:	50 mm x 66 m	36 rolls	8051499033439
PP A 28my white noisy:	50 mm x 132 m	36 rolls	8051499033446
PP A 28my transparent noisy:	50 mm x 66 m	36 rolls	8051499033453
PP A 28my transparent noisy:	50 mm x 132 m	36 rolls	8051499033460
PP A 28my brown no noise:	50 mm x 66 m	36 rolls	8051499033477
PP A 28my brown no noise:	50 mm x 132 m	36 rolls	8051499033484
PP A 28my white no noise:	50 mm x 66 m	36 rolls	8051499033491
PP A 28my white no noise:	50 mm x 132 m	36 rolls	8051499033507
PP A 28my transparent no noise:	50 mm x 66 m	36 rolls	8051499033514
PP A 28my transparent no noise:	50 mm x 132 m	36 rolls	8051499033521

OUR PROPOSAL OF PACKAGING

- Sleeve with B/W or coloured (up to 5 colours) barcode label
- Harmonica
- Tower

RECOMMENDATIONS

It's a good rule to use the product within 6 months from purchase, because the unwinding force of the tape increases with time. The product must be stored in its box in a dry location protected from sunlight, at about $15\,^{\circ}\text{C}$ - $25\,^{\circ}\text{C}$ and 50% relative humidity. If stored in different conditions, the product must be reconditioned. After application, the removal of the tape must be done slowly without tears. Before applying the tape, always check if the surface is clean. Euromask disclaims any liability for any direct or indirect damage coming from the misuse of the product. Under normal conditions, the tape is not toxic and is not approved for medical use.

The a.m. values may be changed at any moment for production needs or technical updates.

rev. 01_May 2019